

Infästningsguide för webertherm 315 fäste



Betong			
Isolertjocklek	webertherm 315 fäste	Minsta sättdjup	webertherm 317 betongskruv
50 mm	45 mm	35 mm	60 mm
80 mm	45 mm	35 mm	100 mm
100 mm	95 mm	35 mm	60 mm
120 mm	95 mm	35 mm	80 mm
140 mm	95 mm	35 mm	100 mm
150 mm	95 mm	35 mm	120 mm
180 mm	95 mm	35 mm	140 mm
200 mm	195 mm	35 mm	60 mm
220 mm	195 mm	35 mm	80 mm
240 mm	195 mm	35 mm	100 mm
250 mm	195 mm	35 mm	120 mm
280 mm	195 mm	35 mm	140 mm
300 mm	195 mm	35 mm	160 mm

Trä			
Isolertjocklek	webertherm 315 fäste	Minsta sättdjup	webertherm 406 träskruv
Cert 50 mm	45 mm	35 mm	80 mm
Cert 80 mm	45 mm	35 mm	100 mm
Cert 100 mm	95 mm	35 mm	80 mm
120 mm	95 mm	35 mm	100 mm
150 mm	95 mm	35 mm	120 mm
180 mm	95 mm	35 mm	160 mm
200 mm	195 mm	35 mm	80 mm
220 mm	195 mm	35 mm	100 mm

Plåtregel			
Isolertjocklek	webertherm 315 fäste	Minsta sättdjup	webertherm 408 plåtskruv
Cert 50 mm	45 mm	10 mm	50 mm
Cert 80 mm	45 mm	10 mm	80 mm
Cert 100 mm	95 mm	10 mm	50 mm

Leca			
Isolertjocklek	webertherm 315 fäste	Minsta sättdjup	webertherm 409 leca-skruv
50 mm	45 mm	60 mm	110 mm
80 mm	45 mm	60 mm	130 mm
100 mm	95 mm	60 mm	110 mm
120 mm	95 mm	60 mm	110 mm
150 mm	95 mm	60 mm	160 mm
200 mm	195 mm	60 mm	110 mm
220 mm	195 mm	60 mm	110 mm
250 mm	195 mm	60 mm	160 mm

Lättbetong			
Isolertjocklek	webertherm 315 fäste	Minsta sättdjup	webertherm 409 leca-skruv
50 mm	45 mm	95 mm	110 mm
80 mm	45 mm	95 mm	130 mm
100 mm	95 mm	95 mm	110 mm